

after entering the last line “./RPi_Cam_Web_Interface_Installer.sh install” appears:





select option 1, appears:



Select ok , install and finish.

start my browser and appears





questions:


As indicated at point c. “In case the installation was successful, the UI of RPi Cam Control should open and you can configure your camera”.


because the file "index.html" is open and no RPI Cam Control


This file says:


“The default Debian document root is `/var/www/html`. You can make your own virtual hosts under /var/www”

when I start the program “camera stream” following happens


CameraStream.project* - CODESYS
Archivo Edición Ver Proyecto Visualización Compilar En línea Depuración Herramientas Ventana Ayuda
PLC_PRG
CODESYS_Control_for_Raspberry_Pi
Visualization
Video Stream
No se puede mostrar página
Asegúrate de que la dirección web http://192.168.1.99 sea correc
Busca la página con tu motor de búsqueda.
Actualiza la página en unos minutos.
Single Picture
Se canceló la navegación a la página web.
100 %
X : 1196, Y : 272
Último Build 0 0
Precompilar:
EN EJECUCIÓN
Programa cargado
Programa inalterado
Usuario actual: (nadie)
ES
21:52
20/10/2015


CameraStream.project* - CODESYS
Archivo Edición Ver Proyecto Compilar En línea Depuración Herramientas Ventana Ayuda
PLC_PRG
CODESYS_Control_for_Raspberry_Pi
CODESYS_Control_for_Raspberry_PiApplication.PLC_PRG
Expresión Tipo de datos Valor Valor preparado Direcci... Comentario
urlStream STRING 'http://192.168.1.99/video.htm'
urlPicture STRING 'http://192.168.1.99/cam_pic.php'
xUpdateStre... BOOL FALSE
xUpdatePict... BOOL FALSE
dwCopySize DWORD 1436
sHostName STRING 'raspberrypi'
Host SysSocket.SOCK_HOSTENT
szHostna... REFERENCE TO STRING 'raspberrypi' Official name of host (network name)
pAliasList POINTER TO POINTER TO STRING 16#00000000 Pointer to list of aliases
pAlia... POINTER TO STRING <Diferenciación de un puntero no válido> Pointer to list of aliases
pA STRING <Diferenciación de un puntero no válido> Pointer to list of aliases
iHostAdd... INT 2 Address type of host
iLengthA... INT 4 Size of host address
pAddrList POINTER TO POINTER TO STRING 16#086A3B90 Pointer to address list
pAd... POINTER TO STRING 16#086A3B10 Pointer to address list
pA STRING 'À¨$01c' Pointer to address list
pIPAddress POINTER TO DWORD 16#086A3B10
pIPAddr... DWORD 1661053120
in_addr INADDR
S_un_b UDINT_IN_BYTES Address for byte-by-byte access
s_b1 BYTE 192 First decimal block, in the example 130
s_b2 BYTE 168 Second decimal block, in the example 094
s_b3 BYTE 1 Third decimal block, in the example 122
s_b4 BYTE 99 Fourth decimal block, in the example 195
S_un_w UDINT_IN_WORDS Address for word-by-word access
s_w1 WORD 43200 First decimal block, in the example 33374
Último Build 0 0
Precompilar:
EN EJECUCIÓN
Programa cargado
Programa inalterado
Usuario actual: (nadie)
ES
21:49
20/10/2015





It may be that the directory of Apache is different from the “camera stream” SysFileCopy (‘/Var/www/Video.htm’) ?

I looked at the directory of IP and it (video.htm) has not created.

Help¡¡